

onix



Blanco
Cod: OX-9501



Plata
Cod: OX-9503



Negro
Cod: OX-9507



Champagne
Cod: OX-9504

METÁLICO



Negro
Cod: OX-9410



Plata
Cod: OX-9403

VIDRIO



Blanco
Cod: OX-9840



Negro
Cod: OX-9850





INTERRUPTOR SIMPLE

-  Cod: OX-5303
-  Cod: OX-6303



INTERRUPTOR DOBLE

-  Cod: OX-5302
-  Cod: OX-6302



INTERRUPTOR TRIPLE

-  Cod: OX-5304
-  Cod: OX-6304



CONMUTADOR SIMPLE

-  Cod: OX-5313
-  Cod: OX-6313



CONMUTADOR DOBLE

-  Cod: OX-5312
-  Cod: OX-6312



CONMUTADOR TRIPLE

-  Cod: OX-5314
-  Cod: OX-6314



TOMA DOBLE UNIVERSAL

-  Cod: OX-5402
-  Cod: OX-6402



TOMA DOBLE ITALIANO

-  Cod: OX-5407
-  Cod: OX-6407



TOMA MULTIFUNCIONAL

-  Cod: OX-5104
-  Cod: OX-6104



TOMA + INTERRUPTOR

-  Cod: OX-5401
-  Cod: OX-6401



TOMA UNIVERSAL + USB

-  Cod: OX-5105U
-  Cod: OX-6105U



PULSADOR DE TIMBRE

-  Cod: OX-5317
-  Cod: OX-6317




INTERRUPTOR + SCHUKO

-  Cod: OX-5403
-  Cod: OX-6403



SENSOR DE MOVIMIENTO

-  Cod: OX-5701
-  Cod: OX-6701



TIMBRE DING - DONG

-  Cod: OX-5702
-  Cod: OX-6702



TOMA MULTIMEDIA

-  Cod: OX-5601
-  Cod: OX-6601



TOMA TELEFONICO

-  Cod: OX-5602
-  Cod: OX-6602



TOMA TELEFONO + TV

-  Cod: OX-5106
-  Cod: OX-6106




DIMMER

-  Cod: OX-5604
-  Cod: OX-6604



TOMA RJ45

-  Cod: OX-5603
-  Cod: OX-6603



TAPA CIEGA

-  Cod: OX-5501
-  Cod: OX-6501